



LAS1206 LAS1007 SINGLE BATWING® FITTING GUIDE



LAS1206



LAS1007

CONTENTS

- LAS1206 Single Batwing® or LAS1007 Single Batwing®

TOOLS REQUIRED

- Tape measure
- Pencil or marker
- Mitre saw or snips

NOTE

Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete any installation detail without prior notice.

For more information please call:

+44 (0)1626 834252

IMPORTANT INFORMATION

Batwing® needs to have a 2 - 4 mm gap between the door and the door stop to enable the door to close. Tight gaps will dislodge the seal from its position.

It is essential to ensure that freshly painted surfaces are fully dry and cured before commencing installation.

The product will not adhere to surfaces where silicone sealant has been applied.

STEP 1

Remove Batwing® from packaging and trim to length using snips.

STEP 2

Peel adhesive from the Batwing® approx 100mm.

STEP 3

Mount in the top corner, using a jointing method as tight as possible to ensure continuity of seal.

STEP 4

Pull adhesive backing strips off a little at a time, progressively pushing Batwing® into place.

NOTE

For single Batwing® there are two preferred positions in the door frame, the flexible seal to be in the same alignment as the double Batwing®.

NOTE

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.



Gasketing materials for fire doors intended for application to wood and plastic covered composite and wood core doors rated up to 1.5 hours. Listed steel frames and/or classified steel covered composite, hollow metal doors rated up to 3 hours.